



RIA Flooding Clean-Up Advisory for Restoration Professionals

Hurricane Katrina provided restoration contractors with the unique opportunity to learn how to respond to massive flooding over a large, affected area. Some of those lessons came at a high price

and offer invaluable information for restoration professionals responding to flooding in the Midwest.

Environmental Contaminants

Due to the variety of contaminants that can be found in the flood waters, proper PPE is crucial for anyone working in the flood-affected areas. There are potential health problems for individuals who have skin contact or inhale any of the contaminants.

Environmental contaminants found in flood waters could include:

- Bacteria – e.g., gram negative bacilli from raw sewage or animal feces
- Heavy Metals – e.g., arsenic, beryllium, cadmium, chromium, copper, lead, nickel, silver, zinc
- Diesel Range Organics – e.g., oil (Note: N-95 filtering masks do not provide adequate protection against oil mist.)
- Pesticides – e.g., DDT, Chlorodane, Heptachlor, non-water soluble organochlorine compounds
- Mold
- PCBs

Health Issues

In New Orleans, contaminants were found in levels high enough to impact the health of those exposed to them. Unprepared workers and volunteers could place themselves at risk for long-term health effects following exposure. Due to testing limitations and a lack of testing standards, these hazards may not be identified until well after workers have been exposed to them.

Injuries and illnesses can include:

- Antibiotic resistant staph infections (MRSA)
- Flesh-eating bacteria
- Intestinal complications
- Respiratory problems
- Exposure to e-coli
- Undiagnosed rashes
- Normal work-related injuries – e.g., falls, vehicle accidents, cuts, bruises

Pittsburgh Protocol

Flood-borne contaminants will impact residents, workers, buildings, vehicles, infrastructure and vegetation. All flood-impacted porous materials should be removed and replaced. Contamination will also be present in semi-porous materials such as studs, sub-flooring and wall sheathing. Any remaining structural components should be thoroughly cleaned following the Pittsburgh Protocol.

The Pittsburgh Protocol was developed in 2004 following Hurricane Ivan and its effects on the Pittsburgh, PA area to deal with mold growth and severe bacterial contamination. There are four basic steps:

1. Using negative pressure containment, structural components should be HEPA vacuumed to remove mud and loose debris.
2. The remaining mold should be treated with a foam application of an antimicrobial/cleaner.
3. Pressure cleaning with an antimicrobial cleaner will remove the visible contamination from surfaces.
4. Then an encapsulant should be applied using an airless paint sprayer to protect the surfaces and inhibit future growth.

What You Should Know

Restoration professionals should be aware that:

- If you haven't been invited to the area, don't go.
- If you do go, preplanning is critical. Most supplies will need to be brought in with contractors – everything from generators, fuel and building supplies to living quarters and food for workers.
- Communication will be difficult, so satellite phones and/or walkie-talkie sets may be necessary.
- Vehicles should be equipped with GPS since many street signs and markers may have disappeared during the flooding.
- Don't offer an opinion or expertise that you don't have. If health issues are involved, refer the client to a doctor.

Cleaning & Safety Procedures

- Fungal growth prefers clean water, so it will not be unusual to find little or no mold growth below the high water mark. There may be fungal contamination in wall cavities due to water wicking up the walls.
- OSB holds more water than plywood.
- **Bleach is a destructive and ineffective antimicrobial and should not be used.**
- Deep contamination requires deep cleaning. Basically, what goes in with water should come out with water. Heavy duty cleaners and degreasers will be needed in addition to agitation.
- Employ aggressive drying strategies.
- In a high humidity situation, high heat is the most effective drying method.
- Open affected areas – including pulling out base moldings and cabinets.

- Plastic-coated electrical wiring can probably be salvaged if cut back to the point of water exposure.
- Treat clothing and textiles with textile compatible conservation treatments.
- Document the damage using photos, video and moisture mapping. Keep a daily log. It's hard to remember what happened months after the fact.
- Remove the damaged materials and hose off or power wash the rest.
- Consider using unmarked trailers to bring in equipment and supplies.
- Train employees on the risks they will encounter, not on every aspect of the job.
- OSHA requires proper PPE, not over protection – Consider: breathable coveralls, P-100 dust masks (more comfortable than half-face respirators), PAPRs.
- Be aware of the symptoms of heat stress and keep employees well hydrated.

Business Basics

- Many homeowners will not have flood insurance, meaning very few will have covered losses. Find out up front who is paying and the payment terms.
- Insurance payments and policies vary – be aware that payments may arrive late or not at all.
- Consider offering a fee-based damage appraisal service. (Can assist your company in pre-qualifying a loss.)
- Know what licenses and legal requirements must be met by contractors for that jurisdiction.
- Make sure to organize your credentials (e.g., state licenses, certifications, etc.) in a presentable manner.
- Verify that your insurance will cover your company in the jurisdiction where you are working.
- Establish lines of credit with banks and equipment suppliers before traveling to the damage area.

These items are in no manner all-inclusive, but are designed to provide restoration professionals with the major issues that should be considered or addressed when working in a flood-damaged area.

For Additional Information

- Restoration Industry Association (formerly the Association of Specialists in Cleaning & Restoration) – www.restorationindustry.org (click on Referrals then Clearinghouse)
 - Contractor Orientation to Catastrophic Disaster Work – RIA Technical Assistance Bulletin (click on Contractor Preparation Tips)
 - The ABC's of Returning to Flooded Buildings – FEMA Recovery Advisory
 - Initial Restoration for Flooded Buildings – FEMA Recovery Advisory
- Health Concerns Associated with Mold in Water-Damaged Homes after Hurricanes Katrina and Rita - U.S. Centers for Disease Control and Prevention – www.cdc.gov
- Federal Emergency Management Agency – www.fema.gov
- American Academy of Experts in Traumatic Stress – www.aaets.org

Special thanks to Frank Headen, CR, WLS, CMH; Michael Pinto, CSP, CMP; and Cliff Zlotnik, CR, WLS, CMH, for sharing their knowledge and expertise.